


FX Clip Rail

The Fx Clip Rail has been specifically designed to be an extremely functional way to hang pictures and other objects that are best displayed with a wall hanging system.

When the Fx Clip Rail is installed, the fixing screws are hidden from view. The rail snaps onto a horizontal row of nylon bushes which are screwed directly to the wall. This is particularly useful if the rail is to be fixed to a hollow partition because some of the bushes can be placed on the vertical studwork. Although the bushes can be fixed anywhere on the horizontal line, **they must support the whole length of the rail.**

INSTALLATION INSTRUCTIONS

- Use a pencil to draw a horizontally level line along the wall where the FX Clip Rail will be placed. Around 10mm below the ceiling or cornice is a good guide.
- For **plasterboard walls**, make sure that you are screwing into the studs and gently into the plasterboard at the centre point between the studs. If there is no available stud at the end of our run then use a wall-mate. You may use wall-mates at any point to increase the strength of the rail fixing.
- For **masonry walls**, drill 6.5mm diameter holes use a hammer of rotary drill at 300-400mm gaps, then insert the green wall plugs.
- Screw in nylon bushes and cut lengths of rail to fit.
- Hang the rail over the nylon bushes at the top, then clip on the rail by pressing firmly near the bottom.



Note: To see a video that covers the installation just described, please visit our website at the address below

Note: We recommend the use of 2 hangers per picture to give weight distribution and allow a flat and straight hang.

Note: We do not recommend our Hanging Systems for hanging of Mirrors.